




## Illustrated Parts List

Portable Generator  
Model 01919




Troy-Bilt® is a registered trademark of Troy-Bilt, LLC and is used under license to Briggs & Stratton Power Products.

Troy-Bilt® es una marca registrada de Troy-Bilt, LLC y se usa abajo licencia a Briggs & Stratton Power Products.

**BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC**  
**JEFFERSON, WISCONSIN, U.S.A.**

## EXPLODED VIEW - MAIN UNIT



Copyright © 2005 Briggs & Stratton Power Products Group, LLC. All rights reserved. No part of this material may be reproduced or transmitted in any form by any means without the express written permission of Briggs & Stratton Power Products Group, LLC.

# Section 1: Exploded Views and Parts Lists

## PARTS LIST - MAIN UNIT

Item	Part #	Description
1	PI94766GS	CRADLE
2	I94150GS	KIT,Vibration, Mount, 45°
4	I90220GS	HOUSING, Engine Adapter
5	NSP	ASSY,Alternator (see page 5)
6	I94151GS	KIT, Hrdwr Mounting Adapter
8	96796GS	WASHER, M8 Flat
10	*	SBHCS, 3/8-16 x 1.0 Lg.
11	I87365FGS	HHCS, 5/16-24 x 7.44
14	I94729GS	KIT, Muffler Bracket w/ Hardware
15	695398	GASKET, Exhaust
17	I89008GS	MUFFLER
18	*	SCREW, 5/16 - 18 x 3/4"
19	83083GS	SCREEN, Spark Arrest
20	B4986GS	DECAL, Ground, Green
21	I94153GS	KIT,Vibration Mount
22	86494GS	SCREW,Wing M6 - 1.0 x 16
23	86292GS	SCREW, 10 - 16 x 3/4, Self Drill
24	I92794GS	SHIELD, Heat
25	I91190GS	CAP
26	74908GS	SCREW, M5-0.8 x 10, Taptite
31	I91436GS	DECAL, Hot Muffler
34	I95422GS	COVER, Bearing Carrier
35	I94397GS	KIT, Fuel Hose, Formed w/ Clamps
37	I92376GS	SCREW, 12-24 x 1/2 Thrd forming
38	56893GS	CRIMPTITE, 10 - 24 x 1/2
40	I94398GS	KIT, Fuel Tank Hardware
41	I92980GS	KIT, Valve, Fuel Tank
44	I93668GS	ASSY, Tank, Fuel (Includes Items 41, 50, 51 & 52)
45	B4363GS	CAP, Fuel Gauge
48	I95373GS	WIRE, Ground
50	I88333GS	DECAL, Gas Fill
51	I94799GS	DECAL, Danger
52	I89235GS	DECAL, Start Instructions
55	I91435GS	DECAL, Shut-Off, Fuel
58	I90355GS	ASSY, Control Panel (see page 4)
59	*	NUT, Palnut, 3/16"
900	§	ENGINE

### Parts Not Illustrated


MS5242	MANUAL, Engine
I92258GS	MANUAL, Owners
BB3061GS	BOTTLE, Oil
I88971GS	CORD, Extension, 120/240V, 30A
I93667GS	KIT, Decals

\* - Items shown without part numbers are common fasteners found at your local hardware store.

§ - Contact Engine Manufacturer

## Section 1: Exploded Views and Parts Lists

### CONTROL PANEL EXPLODED VIEW & PARTS LIST




Item	Part #	Description
1	195112GS	KIT, Control Panel Lid
2	188889GS	CONTROL PANEL, Compact
6	68759GS	OUTLET, 120V, 20Amp, Duplex
7	*	NUT, Palnut, Pushnut, 5/32
8	84198GS	CAP, Circuit Breaker
9	75207GS	BREAKER, Circuit
10	43437GS	OUTLET, 120/240V Locking, 30A
11	*	NUT, Palnut, Pushnut, 3/16
12	*	SCREW, Phillips, Head 3.5 x 18
13	93857GS	BAR, Retaining
14	188890GS	COVER, Back, Control Panel
15	82308GS	SCREW, Self Tapping, STC 3 x 18
16	22694GS	HOUSING, Receptacle
17	*	SCREW, Phillips, 3.5 x 14

\* - Items shown without part numbers are common fasteners found at your local hardware store.

## Section 1: Exploded Views and Parts Lists


### ALTERNATOR EXPLODED VIEW AND PARTS LIST



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	190032GS	ROTOR
3	190079AGS	STATOR
4	186060GS	RBC, with O-Ring (p/n 189197GS)
5	86308HGS	HHCS, M6 - 1.0 x 140 SEMS
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	TAPTITE, M5 - 0.8 x 16
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll, 4mm x 10
10	193428AGS	ASSY, Wire, Ground
13	194274GS	HARNESS, Wire, Power

## Section 1: Exploded Views and Parts Lists

### WHEEL KIT EXPLODED VIEW AND PARTS LIST



Item	Part #	Description
1	I89715GS	ASSY, Handle
2	B1764GS	LEG, Mounting
3	52858GS	NUT, Locking Hex M8 - 1.25
4	*	HHCS, M8 - 1.25 x 45
5	I91267HGS	AXLE, 5/8" x 22.87"
6	B4966GS	WHEEL
7	I91265GS	E-RING
8	*	WASHER, Flat 5/8
9	*	HHCS, M8 - 1.25 x 16

#### Parts Not Illustrated

I89718GS	GRIP
I89716GS	CAP, Handle End

\* - Items shown without part numbers are common fasteners found at your local hardware store.