Hampton Bay Wall-Mount 4-Light Outdoor Flemish Lantern



Description

The Hampton Bay Wall-Mount 4-Light Outdoor Flemish Lantern features transitional styling and simple contours that match it to a variety of architectural styles with ease. It's made from durable steel and finished in Flemish bronze for an antique look. The fixture's clear glass is seeded for a bright and interesting diffusion of light.

- Steel construction finished in Flemish for an antique look
- Clear seeded glass for a bright and shimmering diffusion of light
- Transitional styling matches many home decors
- Wall-mount design for porches, patios and facades
- Weather-resistant housing for long service life
- Uses 4 candelabra bulbs up to 60-watts each (included)
- MFG Brand Name: Hampton Bay
- MFG Model #: HD296106
- MFG Part #: Y38004STL-197

Specifications

- Assembled Depth (in.): 12.25 in
- Assembled Height (in.): 22.25 in
- Assembled Width (in.): 11.0 in
- **Bulb Type**: Incandescent
- **CSA Listed**: No
- Color/Finish: Flemish

Dusk to Dawn: No ETL Listed: No

• Energy Star Compliant: No

• Exterior Lighting Product Type: Wall Mount Light

• Fixture Finish: Flemish

• Fixture Material: Steel, Glass

Glass/Lens Type: Seedy
 Light Source: Incandescent
 Manufacturer Warranty: N/A
 Maximum Bulb Wattage: 60.0 W

• Motion Sensor: No

Number of Bulbs Required: 4
Product Height (in.): 22.25 in
Product Length (in.): 12.25 in
Product Weight (lb.): 15.87 lb
Product Width (in.): 11 in

• **Returnable**: 90-Day

• Size: Large

Solar Powered: NoStyle: Classic

• Weather Resistant: Yes



OUTDOOR FIXTURE INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

Turn off the main power at the circuit breaker before installing the fixture, in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.


ASSEMBLY AND INSTALLATION

- 1. Thread the #8-32 HEX NUTS (5) onto the #8-32 FIXTURE MOUNTING SCREWS (2), and screw the SCREWS (2) onto the MOUNTING BRACKET (3), without tightening the #8-32 HEX NUT (5).
- 2. Pull the power supply wires out from the OUTLET BOX (1), and mount the MOUNTING BRACKET (3) to the OUTLET BOX (1), using MOUNTING SCREWS (4).
- 3. Place the BACK PLATE (13) of the fixture over the OUTLET BOX (1) and onto the FIXTURE MOUNTING SCREWS (2), and adjust the HEX NUTS (5) until it protrudes 1/4" out from the BACK PLATE (13). Remove the BACK PLATE (13) and secure the position of the SCREWS (2) by tightening the HEX NUT (5) against the MOUNTING BRACKET (3).
- 4. Attach the BLACK SUPPLY WIRE (9) to the BLACK FIXTURE LEAD WIRE (10) by using the WIRE CONNECTOR (8). In the same manner, attach the WHITE SUPPLY WIRE (7) to the WHITE FIXTURE LEAD WIRE (12). Connect the FIXTURE GROUND WIRE (11) to the POWER SUPPLY GROUND WIRE (6) using a WIRE CONNECTOR (8).
- 5. Place the BACK PLATE (13) back onto the FIXTURE SCREWS (2), and secure into place using the DECORATIVE NUTS (14) provided.

ASSEMBLY AND INSTALLATION (Continued)

6. Slide the candle cover onto the socket, Screw light bulbs into the threaded sockets and make sure they do not exceed the maximum wattage specified on the fixture's wattage rating label.

INSTALLATION IS NOW COMPLETED



- 1. OUTLET BOX
- 2. #8-32 FIXTURE MOUNTING SCREW
- 3. MOUNTING BRACKET
- 4. MOUNTING SCREW
- 5. #8-32 HEX NUTS
- 6. POWER SUPPLY GROUND WIRE
- 7. WHITE SUPPLY WIRE
- 8. WIRE CONNECTOR

- 9. BLACK SUPPLY WIRE
- 10. BLACK FIXTURE LEAD WIRE
- 11. FIXTURE GROUND WIRE
- 12. WHITE FIXTURE LEAD WIRE
- 13. BACK PLATE
- 14. DECORATIVE NUT