


Foundation Legs Assembly Instructions

The Foundation Legs should be installed after **steps 4a and b** of the Foundation Assembly section in the Owner's Manual.

Note: If you have an existing foundation, check to see if there are pre-drilled holes in the side rails (as shown below). If not, see other side for instructions.

4c

Attach the Legs



1. Insert bolt through bracket (if applicable), side rail, and leg holes. Hand-tighten washer and wing nut. Repeat for other hole and tighten firmly.
2. Repeat for remaining 2 legs on same side (middle and end), and 3 remaining legs on other side of bed.
3. Make sure washer and wing nut are tight and head of carriage bolt is flush with side rail.
4. If you have a king size bed, repeat the steps above for your second foundation.
5. Continue with **steps 5 and 6** in the Owner's Manual to complete the foundation assembly.

Retro Fit Foundation Legs Instructions

If your foundation does not have pre-drilled holes for the Foundation Legs, follow instructions below.

Note: If your foundation has pre-drilled holes in the side rails, see other side.

Drill Holes

1. At corner of foundation, position leg (as shown in diagram 1) and slide leg towards the head or foot of bed. Leave approximately a finger-width in the side rail channel as shown in diagram 2.
2. Using leg holes as a guide, firmly hold the leg in place and drill completely through foundation with a 5/16" drill bit.
(Be sure hand and fingers are clear from drill bit on outside of side rail.)
3. Repeat steps 1 and 2 for each of the 4 corners.
4. On middle of side rail, approximately center a leg between the 2 middle support beams and drill holes. Repeat for other side of bed.
5. Complete **step 4c** on page 1 to attach Foundation Legs.

