

Step 1

Push stem of rug roller into leg socket until it locks into place as shown in **Detail A**.

NOTE: Place locking rollers at the foot of the bed.

Step 2

Assemble cross arms to side rails by sliding inner leg bracket into the outer leg bracket until the top of the cross arm is level with side rail. This may require light tapping with a hammer. See **Detail B**.

Step 3


For King & California King beds only. Lock center support into cross arms by sliding inner leg bracket into outer leg bracket until top of center support is even with the cross arm. This may require light tapping with a hammer. See **Detail C**.

Step 4


Place end caps on end of side rails. Slide foundation retainer caps on foundation retainer brackets until they snap into place.

99300607
4/02


Twin, Full & Queen




King & California King



Detail A.



Detail B.



Detail C.

